


NIDA TOOLS

ELECTRIC NAILER

**ELECTRIC TACKER
ET-1835**



GB

CE DECLARATION OF CONFORMITY

We declare under our sole responsibility that this product is in conformity with the following standards or standardized documents: EN 60 745, EN 55 014, EN 61000, in accordance with the provisions of the directives 2006/95/EC, 2004/108/EC, 2006/42/EC.

Subject to change without notice.





Handwriting practice lines consisting of 20 horizontal lines.

1

ET-1835

220
240
V~9A
50Hz



MAX 100




20/min

2 mtrs

1.66Kg

a=1.25mm
b=1.8-2.0mm
c=15, 20, 25, 30, 32mm
d=1mm



This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and extend across the width of the page. There are no margins, text, or other markings on the paper.

g) **Use the power tool, accessories and tool bits etc., in accordance with these instructions and in the manner intended for the particular type of power tool, taking into account the working conditions and the work to be performed.** Use of the power tool for operations different from those intended could result in a hazardous situation.

5) SERVICE

a) **Have your power tool serviced by a qualified repair person using only identical replacement parts.** This will ensure that the safety of the power tool is maintained.

SAFETY INSTRUCTIONS FOR TACKERS

- **Secure the workpiece** (a workpiece clamped with clamping devices or in a vice is held more securely than by hand)
- **Never push in the tacker head manually** ④ (there is danger of injury when at the same time the trigger is activated unintentionally)
- **Never use the tool for fastening electrical wiring** (contact with electrical wires can lead to fire and electric shock)
- Avoid damage that can be caused by screws, nails and other elements in your workpiece; remove them before you start working
- Always check that the supply voltage is the same as the voltage indicated on the nameplate of the tacker (tackers with a rating of 230V or 240V can also be connected to a 220V supply)
- In case of electrical or mechanical malfunction, immediately switch off the tool.
- VIDA TOOLS can assure flawless functioning of the tool only when original accessories are used
- This tool should not be used by people under the age of 16 years
- Do not expose tool to rain. ⑤

USE

- Loading nails ⑥
 - tilt the tool or lay the tool flat, so the nails will not drop out while loading
 - press lever A while pulling slider B backwards
 - place the nail strip into magazine C (maximal capacity 100 nails)
- ! **Attention**
Make sure that
 - the nail strip is loaded with the tapered end aligning with the bottom line of the magazine C, so the brad nail head rest right into the grooves which corresponds with the symbol of nail length on tacker head D ⑦
 - push slider B against tacker head D until it snaplocks
- Operating the tool ⑧
 - firmly press tacker head D against the workpiece until it is pushed in a few millimeters
 - briefly press trigger F and then release again
 - Trigger F is locked as long as you do not press tacker head D against the workpiece, thus preventing accidental operation
 - At 20 shots/min, tacker should be allowed to cool down after 30 minutes as it is only rated for short-time duty.
- ! **remove all staples/nails from the magazine after each use**

- Impact control ⑨
 With knob G the required impact level can be adjusted
 - indicator G shows the selected impact level
 - “-” for thin and light materials such as foils and fabrics
 - “+” for thick and tough materials such as hard woods and walls
 - before starting a job, find the optimal impact level by testing out on spare material

APPLICATION ADVICE

- Fastening panels ⑩
- Do not use the tool for fastening ceiling panelling on profiled wood or grooves
- Fixing textiles ⑪
- Avoid blank shots in order to reduce the wear of the impact strike

NAIL INSTRUCTIONS FOR TACKERS




- Roughly, the hardness of wood is divided into 3 levels: ⑫
 - High
 - Medium
 - Low
- Nails of different length are applicable for different wood hardness
- The tool has a recoil when firing, so two hands operation is suggested, to have a better control of the operation


UNBLOCKING JAMMED FASTENERS



- In the unlikely event that nails become jammed, follow these instructions to remove them
- ! **unplug power cord from power source before removing**
 - Remove the nose tip I ⑬
 - Remove the plate retaining bolts C1 ⑭
 - Remove the safety mechanism retaining plate C2 ⑮
 - Remove the firing pin retaining plate C3 ⑯
- ! **Note the location as well as the order in which parts are removed from the tacker, this will make it easier to rebuild it**

GUARANTEE / ENVIRONMENT

- Keep tool clean
- ! **unplug power cord from power source before cleaning**
- This product is guaranteed in accordance with statutory/country-specific regulations; damage due to normal wear and tear, overload or improper handling will be excluded from the guarantee
- In case of a complaint, send the tool or charger **undismantled** together with proof of purchase to your dealer or the nearest authorized service station
- **Do not dispose of electric tools, accessories and packaging together with household waste material** (only for EU countries)
 - in observance of European Directive 2006/95/EC on waste of electric and electronic equipment and its implementation in accordance with national law, electric tools that have reached the end of their life must be collected separately and returned to an environmentally compatible recycling facility
 - symbol ⑰ will remind you of this when the need for disposing occurs



⑫				
NO.	Wood	Wood hardness	Length of nail (mm)	Hand Operation
1	Beech Wood	High	15, 20, 25	 Two hands operation (see picture). One hand operation is not suggested.
2	Oak		15, 20, 25	
3	Medium Density Fiberboard	Medium	15, 20, 25, 30	
4	Solid Wood		15, 20, 25, 30	
5	Pine	Low	15, 20, 25, 30, 32	
6	plywood		15, 20, 25, 30, 32	
7	Cedar		15, 20, 25, 30, 32	



GB

INTRODUCTION

- This tool is intended for nailing of cardboard, insulating material, fabrics, foils, leather and similar materials on surfaces of wood or materials similar to wood
- Read and save this instruction manual ③

TECHNICAL SPECIFICATIONS ①

TOOL ELEMENTS ②

- A Lever for loading magazine
- B Slider
- C Magazine
- D Tacker head
- E Soft grip handle
- F Trigger
- G Impact control adjustment knob
- H On/off switch
- I Non-marring nose tip

SAFETY

GENERAL SAFETY INSTRUCTIONS

WARNING! Read all instructions. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury. The term "power tool" in all of the warnings listed below refers to your mains operated (corded) power tool or battery operated (cordless) power tool.

1) WORK AREA

- Keep work area clean and well lit.** Cluttered and dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust.** Power tools create sparks which may ignite the dust or fumes.
- Keep children and bystanders away while operating a power tool.** Distractions can cause you to lose control.

2) ELECTRICAL SAFETY

- Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools.** Unmodified plugs and matching outlets will reduce risk of electric shock.
- Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges and refrigerators.** There is an increased risk of electric shock if your body is earthed or grounded.
- Do not expose power tools to rain or wet conditions.** Water entering a power tool will increase the risk of electric shock.

- Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts.** Damaged or entangled cords increase the risk of electric shock.

3) PERSONAL SAFETY

- Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication.** A moment of inattention while operating power tools may result in serious personal injury.
- Use safety equipment. Always wear eye protection.** Safety equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
- Remove any adjusting key or wrench before turning the power tool on.** A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- Do not overreach. Keep proper footing and balance at all times.** This enables better control of the power tool in unexpected situations.
- Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts.** Loose clothes, jewellery or long hair can be caught in moving parts.
- If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used.** Use of these devices can reduce dust related hazards.

4) POWER TOOL USE AND CARE

- Do not force the power tool. Use the correct power tool for your application.** The correct power tool will do the job better and safer at the rate for which it was designed.
- Do not use the power tool if the switch does not turn it on and off.** Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- Ensure the switch is in the off position before making any adjustments, changing accessories, or storing power tools.** Such preventive safety measures reduce the risk of starting the power tool accidentally.
- Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool.** Power tools are dangerous in the hands of untrained users.
- Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tools operation. If damaged, have the power tool repaired before use.** Many accidents are caused by poorly maintained power tools.
- Keep cutting tools sharp and clean.** Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.